

(Importers and Distributors of Electronic Equipment)  
11 Normanby Street, Prahran, Vic. 3181, Australia  
PO Box 3167  
Telephone: (03) 9529 3660 International: 61 3 9529 3660  
Fax: (03) 9529 7524 International: 61 3 9529 7524  
E-mail: sales@interscientific.com.au  
Web: www.interscientific.com.au

There are two important requirements for installing an accelerometer, and both of these requirements must be met for optimum sensor operation.

1. Proper sensor location - this is often dictated by the bearing type and/or machine operation.
2. A clean, accurate mounting surface for the sensor.

The installation kits from 'General Systems' (Part No's. 831000 & 842000) have been designed to help the installer mount the sensors cleanly, accurately, and quickly - **\$350 plus GST.**

A key component of the installation kit is the 'Spot-Facer tool with Guide-Pin'.

Below is a diagram of the 25 mm Spot-Facer tool we hold in stock - **\$120 plus GST.**

Guide-Pins are interchangeable and come in 1/4-28 and 10-32 sizes.



Plan - Drawing Approx. same size



End Elevation